



# Power Supply User Manual



A complete set of Universal Adapter includes:

- An adapter with output cord (x1)
- Two-flat-pin prongs (x1)
- Two-round-pin prongs (x1)
- Three-pin prongs (x1)



How to change the prong:

1. Press down the locking button firmly.
2. Pull the unwanted prong out from the Adapter.
3. Select the suitable prong for your country.
4. Align and slide the prong into the slot of adapter.
5. Until hear the “click” sound and locked the prong onto the adapter
6. Pull back the prong to ensure installation properly.

